SELECTING INSTANCE

Toggle between controlling MASCHINE or Ableton Live with the hardware — SHIFT + PLUG-IN Instance

TRANSPORT CONTROL

Start playback — ▶ PLAY

Start session record — ● REC Count-In

Start arrangement record — SHIFT + ● REC Count-In

Stop playback/recording — ■ STOP

Enable/disable loop mode — SHIFT + RESTART Loop

Enable/disable metronome — SHIFT + TAP Metro

Tap tempo — TAP Metro

EDIT CONTROL

Undo action — SHIFT + 1

Redo action — SHIFT + 2

Quantize to grid value — SHIFT + 5

Toggle automation arm — AUTO

SESSION CONTROL

Select tracks

Select clip in track

Start/stop selected clip

MIXER CONTROL

Mute/unmute track — MUTE Choke + 1-8

Solo/unsolo track — SOLO + 1-8

Jump to a track — 1-8

Switch track bank — ◀ ▶

Set knob 1-8 to control panorama — SHIFT + knob

Set knob 1-8 to control volume — SHIFT + knob

Coarse adjust panorama/volume of selected track — 1-8

Fine adjust panorama/volume of selected track — SHIFT + 1-8

SELECTING INSTANCE

Toggle between controlling MASCHINE or Logic Pro with the hardware — SHIFT + PLUG-IN Instance

TRANSPORT CONTROL

Start playback — ▶ PLAY

Start recording — ● REC Count-In

Enable/disable count-in — SHIFT + ● REC Count-In

Stop playback/recording at current position — ■ STOP

Enable/disable loop mode — SHIFT + RESTART Loop

Move loop by its own length — RESTART Loop +

Enable/disable metronome — SHIFT + TAP Metro

Tap tempo — TAP Metro

EDIT CONTROL

Undo action — SHIFT + 1

Redo action — SHIFT + 2

Quantize to grid value — SHIFT + 5

Toggle automation between read mode and touch mode — AUTO

MIXER CONTROL

Mute/unmute track — MUTE Choke + 1-8

Solo/unsolo track — SOLO + 1-8

Jump to a track — 1-8

Select previous/next track — 

Switch track bank — ◀ ▶

Set knob 1-8 to control panorama — SHIFT + 

Set knob 1-8 to control volume — SHIFT + 

Coarse adjust panorama/volume of selected track — 1-8

Fine adjust panorama/volume of selected track — SHIFT + 1-8